

INSTALLATION INSTRUCTIONS

FLOOD VENT SEALING KIT 1540-526



TUTORIAL



Prepare Opening

See table to the right for measurements. Ensure the inside and outside are clear of debris.

MODEL	OPENING SIZE
1540-526	16 1/4"W x 8 1/4"H
1540-526-2	16 1/4"W x 16 3/8"H
1540-526-4	33"W x 16 3/8"H
1540-526-201	32 3/4"W x 8 1/2"H



Remove Sealing Kit from Packaging

Use caution when opening with a blade. Puncturing too deep can damage the product.



Apply Sealant on Flange

Use HurriBond or an equivalent adhesive on all edges of the back side of the Sealing Kit Flange.



Install Sealing Kit into Interior Opening

Homasote tiles are fragile. Handle with care. Compress the frame to the wall for 1 minute.



Check Frame Placement

Make sure Sealing Kit frame is level, flush with the wall, and firmly adhered.

REPLACE YOUR SEALING KIT

Scan the QR code for a video tutorial on replacing your sealing kit with the 1540-526-R.



MAKE VENT INSTALLS A BREEZE

HurriBond is a fast-curing, multi-purpose silicone sealant and adhesive. Comes in gray or white. 1 tube for every 5-6 vents.

